



GAP SAND

Forms a workable yet stable joint between pavers, up to 3mm gap
Inhibits weed & insect infestation
Minimises paver distortion
Covers approx 3.5m² for brick shaped pavers; 12m² for 400mm square pavers, 50mm depth



GAP SAND

- ✓ Inhibits weed growth and insect infestation
- ✓ Allows slight movement without distortion or cracking
- ✓ Forms a firm bond between pavers when dry
- ✓ Assists in maintaining joint integrity and stability
- ✓ Quick and easy to use

Build with Confidence

cementaustralia.com.au





GAP SAND

Forms a workable yet stable joint between pavers, up to 3mm gap
 Inhibits weed & insect infestation
 Minimises paver distortion
 Covers approx 3.5m² for brick shaped pavers, 12m² for 400mm square pavers, 50mm depth



PAVER
JOINTFILL



INHIBITS
WEEDS



STABILISE
PAVERS

Cement Australia Gap Sand is a special blend of graded fine sands and additives designed to help lock into place all types of brick and block paving.

Gap Sand can be used with all types of paving and is ideal in areas of heavy traffic movement, high wind areas, driveways, pool surrounds, sloping sites and for topping up existing paving.

- ✓ Gap Sand inhibits weed growth and insect infestation by forming a firm but pliable joint between each paver, allowing slight movement without distortion or cracking
- ✓ When re-wet through rain or hosing, Gap Sand forms a pliable Gel which returns to the firm bond between the pavers once it is dry
- ✓ Assists in maintaining joint integrity and stability
- ✓ Quick and easy to use

HOW TO USE

- STEP 1** Lay pavers as per manufacturer's instructions. Sweep Gap Sand into all joints using a stiff broom, until all gaps are filled.
- STEP 2** Work a vibrating compactor, rubber mallet or similar piece of equipment over the entire paved area to assist the flow of filler into the joints and to ensure the joints are firm.
- STEP 3** Thoroughly sweep the paved surface, topping up where necessary and remove all excess surface sand.
- STEP 4** Mist spray the paved surface ensuring that all areas receive a thorough wetting. Avoid heavy spraying or flooding of areas. Allow 3 days for the Gap Sand to bond the pavers into place before using the paved area.



Correct paving gap showing bonded Gap Sand between pavers



Insufficient paving gap showing Gap Sand sitting on top of pavers

Please note: Colour results may vary - the colour of the finished product may vary due to natural differences in raw materials.

Item Code 17734

Cement Australia
Gap Sand 20kg



9 311808 035400



LOCALLY MADE
AUSTRALIAN
PRODUCT



Safety Data Sheet available at cementaustralia.com.au